

Product Information

D894 High Solids Clear (California)

Product Description

D894 High Solids Clear is a premium quality high solids clearcoat specifically formulated to give optimum gloss and durability.

D894 is designed for use over Global BC Colour (see Data Sheet EU02).

Preparation of Substrate



In all cases, wash all surfaces to be painted with soap and water, then apply the appropriate Global cleaner. See GLG-142 Global Cleaners bulletin for selection and usage instructions. Ensure that the substrate is thoroughly cleaned and dried both before and after application work.



Wet sand with European P800-1200 / U.S. 500-600 grade paper or dry sanding with European P600-800 / U.S. 400-500 grade paper.



Wash off residue and dry thoroughly before recleaning with appropriate Global substrate cleaner. The use of a tack rag is recommended.

Apply Global BC Colour over original stoved finishes or over recommended Global Primers. See Data Sheet EU02 for Global BC system application details.

Product Information Effective 12/09 EU-100CA

APPLICATION GUIDE

Mixing Ratio:



D894 3 vols Hardener 1 vol **D-Thinner** 1 vol

Hardener Selection

Thinner Selection

D884 Air Dry / General Purpose D8764 Fast Compliant Thinner D887 Stoving / Mar Resistance D8767 Compliant Thinner

D8774 Medium Compliant Thinner Smaller areas may require faster thinner. Note:

Potlife:



@ 20°C / 68°F 5 - 6 hours

Additives:



Use **D885 Enhancer** for enhanced cure Add ¹/₂ fl. oz. per ready to-spray U.S. quart. Use **D886 Extender** to extend cure Add 1/2, fl. oz. per ready to-spray U.S. quart. Use *D759 Matting Base* to flatten D894 Clear See EU-33 for application instructions. Use **D814 Plasticiser** to flexibilize D894 Clear See EU-47 for application instructions.

Spraygun set-up:

Fluid Tip 1.3 - 1.5 mm or equivalent

Spray Viscosity 17 - 18 secs #2 ZAHN (Signature type @ 20°C / 68°F

Spray pressure:



0.7 bar / 10 PSI HVLP at air cap 3 - 4 bar / 45 - 55 PSI Conventional at spray gun

Number of coats:



Apply 2 normal coats Film build per wet coat 2.4 - 3.0 milsDried film build per coat 1.0 - 1.25 mils

Flash off at 20°C / 68°F:



Between coats 5 - 10 minutes 0 - 15 minutes Before stoving

Drying times:



Dust-free 20°C / 68°F 30 - 45 minutes Dry to handle



20°C/68°F 3 - 4 hours 60°C / 140°F 30 minutes



Tape Time 20°C / 68°F 7 - 8 hours 60°C / 140°F 30 minutes



Through Dry 20°C/68°F 8 hours 60°C / 140°F 30 minutes



IR (infrared) Medium Wave 15 minutes Short Wave 8 minutes

Note: All force dry times are quoted for metal temperature. Additional time must be allowed during force dry to allow metal to reach recommended temperature.

APPLICATION GUIDE

Overcoat / Recoat:



Overcoat/Recoat Time



 Grade wet
 European P800 – 1200 / U.S. 500 – 600

 Grade dry
 European P600 – 800 / U.S. 400 – 500



Overcoat with Any Global topcoat system

Performance Guidelines:

Allow the Global BC Colour to flash off for 15 minutes (but no longer than 24 hours) before applying D894 Clear. The timing will depend on thickness and temperature.

6 – 8 hours @ 20°C / 68°F or after force dry/cool down

Recoating times will be extended at lower temperatures. Global D894 may be sanded with 1200 grit paper or finer and polished when hard, to rectify minor imperfections.

Fading Out - D894 Clear After spot repairing, clean the gun and then spray Global Blending Thinner D853 around the repaired area to lose the edge and blend the repair into the surrounding panel. Spray starting from the outside of the repair, moving to the center.

Technical Data:

Total dry film build

 $\begin{array}{ll} \mbox{Minimum} & \mbox{50}\mu\mbox{m} \ / \ 2.0 \ \mbox{mils} \\ \mbox{Maximum} & \mbox{75}\mu\mbox{m} \ / \ 3.0 \ \mbox{mils} \end{array}$

Recommended film build per wet coat $40-75\mu m \ / \ 2.4-3.0 \ mils$ Recommended dried film build per coat $25-31\mu m \ / \ 1.0-1.25 \ mils$

Theoretical coverage 16.45 m² per litre / 669.51 sq. ft. per US gal.

Note: Theoretical coverage in m² /litre and sq.ft./US gal. Ready-to-spray (RTS), giving 25 and (1 mile) dry film thickness.

giving 25 µm (1 mils) dry film thickness.

Percent solids by volume RTS

VOC

(D894) 483.6 gms per litre / 4.03 lbs. per US gal. (D894:D887:D8767, 3:1:1) 405.6 gms per litre / 3.38 lbs. per US gal.

43.3

Product Compatibility:

D894 may be applied over any Global basecoat

Health and Safety:

See Material Safety Data Sheet and Labels for additional safety information and handling instructions.



• The contents of this package may have to be blended with other components before the product can be used. Before opening the packages, be sure you understand the warning messages on the labels and MSDS's of all the components, since the mixture will have the hazards of all its parts.



 Improper handling and use, for example, poor spray technique, inadequate engineering controls and/or lack of proper Personal Protective Equipment (PPE), may result in hazardous conditions or injury.



- · Follow spray equipment manufacturer's instructions to prevent personal injury or fire.
- Provide adequate ventilation for health and fire hazard control.
- Follow company policy, product MSDS and respirator manufacturer's recommendations for selection and proper use of respiratory protection. Be sure employees are adequately trained on the safe use of respirators per company and regulatory requirements.
- · Wear appropriate PPE such as eye and skin protection. In the event of injury, see first aid procedures on MSDS.
- · Always observe all applicable precautions and follow good safety and hygiene practices.

Emergency Medical or Spill Control Information (412) 434-4515; In Canada (514) 645-1320

Materials described are designed for application by professional, trained personnel using proper equipment and are not intended for sale to the general public. Products mentioned may be hazardous and should only be used according to directions, while observing precautions and warning statements listed on label. Statements and methods described are based upon the best information and practices known to PPG Industries. Procedures for applications mentioned are suggestions only and are not to be construed as representations or warranties as to performance, results, or fitness for any intended use, nor does PPG Industries warrant freedom from patent infringement in the use of any formula or process set forth herein.

PPG Industries 19699 Progress Drive Strongsville, OH 44149

PPG Canada Inc. 2301 Royal Windsor Drive, Unit #6 Mississauga, Ontario L5J 1K5

©2009 PPG Industries EU-100CA 12/09